









SYSTEM VIEW



SYSTEM SECTION DETAIL





↔ EBAT
↔ SIZE

🔥 YANGIN SINIFI
FIRE PERFORMANCE

♻️ GERİ DÖNÜŞÜM
RECYCLED CONTENT

🔊 SES EMİLİMİ
SOUND ABSORPTION (NRC)

🏠 YÜZEY
SURFACE

🏋️ SİSTEM AĞIRLIĞI
SYSTEM WEIGHT

🔪 PERFORASYON
PERFORATION

🏆 KALİTE BELGESİ
QUALITY

CONTACT



tacerakustik



tacerakustik



tacerinsaat



tacerakustik

Head Office:

Birlik Mah. 450.Cad. No:79/B Çankaya/Ankara/TURKEY 06610
Tel: +90 312 496 11 05

Izmir Office:

Çınarlı Mah. Ozan Abay Cad. Ege Perla B-Blok No:10 Kat:6 D:65
Konak/Izmir/TURKEY 35170
Tel: +90 232 472 06 43

Factory 2:

O.S.B. Kızılırmak Cd. 1. Sk. No:15 Yahşiyân/Kırıkkale/TURKEY 71450
Tel: +90 318 321 33 50

Istanbul Office:

Esen-tepe Mah. E-5 Yan yol:Kelebek Sk. Marmara Kule No:17 Kat:12
Kartal/Istanbul/TURKEY 34870
Tel: +90 216 469 44 84

Factory 1:

Esenboğa Yolu 22 km. Saracalar Mah. Kümeevler Sk. No:46
Akyurt/Ankara/TURKEY 06750
Tel: +90 312 399 25 45

Factory 3:

Ostim Fabrika İvedik Org. San. Genç Kardeşler Sitesi 1468. Cad. 2286. Sok.
No:44-46-48-50
Ostim/Ankara/TURKEY 06378
Tel: +90 312 395 27 36