









# SYSTEM VIEW



# SYSTEM SECTION DETAIL



**AHŞAP GÖRÜNÜM SEÇENEKLERİ  
VE TÜM RAL RENKLERİ**

↔ EBAT  
↔ SIZE

🔥 YANGIN SINIFI  
FIRE PERFORMANCE

♻️ GERİ DÖNÜŞÜM  
RECYCLED CONTENT

🔊 SES EMİLİMİ  
SOUND ABSORPTION (NRC)

🏠 YÜZEY  
SURFACE

🏋️ SİSTEM AĞIRLIĞI  
SYSTEM WEIGHT

🔪 PERFORASYON  
PERFORATION

🏆 KALİTE BELGESİ  
QUALITY

## CONTACT

[tacerakustik](#) [tacerakustik](#) [tacerinsaat](#) [tacerakustik](#)

### Head Office:

Birlik Mah. 450.Cad. No:79/B Çankaya/Ankara/TURKEY 06610  
Tel: +90 312 496 11 05

### Izmir Office:

Çınarlı Mah. Ozan Abay Cad. Ege Perla B-Blok No:10 Kat:6 D:65  
Konak/Izmir/TURKEY 35170  
Tel: +90 232 472 06 43

### Factory 2:

O.S.B. Kızılırmak Cd. 1. Sk. No:15 Yahşıyan/Kırıkkale/TURKEY 71450  
Tel: +90 318 321 33 50

### Istanbul Office:

Esen-tepe Mah. E-5 Yan yol Kelebek Sk. Marmara Kule No:17 Kat:12  
Kartal/Istanbul/TURKEY 34870  
Tel: +90 216 469 44 84

### Factory 1:

Esenboğa Yolu 22 km. Saracalar Mah. Kümeevler Sk. No:46  
Akyurt/Ankara/TURKEY 06750  
Tel: +90 312 399 25 45

### Factory 3:

Ostim Fabrika İvedik Org. San. Genç Kardeşler Sitesi 1468. Cad. 2286. Sok.  
No:44-46-48-50  
Ostim/Ankara/TURKEY 06378  
Tel: +90 312 395 27 36